

Disinfection of hunting and target rifles

For the disinfection of ANSCHÜTZ hunting and target rifles we recommend a water-based surface disinfectant with the lowest possible alcohol ingredient.

- For the disinfection of ANSCHÜTZ hunting and target rifles, we recommend a water-based surface disinfectant with the lowest possible alcohol content.
- When cleaning a hunting or target rifle, the safety of the rifle must be guaranteed. Please review the operating instructions for your ANSCHÜTZ rifle.
- Test the detergent / disinfectant in an inconspicuous area on the rifle before use. Aggressive detergents or disinfectants can damage the surface finish (paints, varnishes, anodized surfaces or other sensitive areas) of your rifle.
- Do not use spray type disinfectants; the spray cloud can inadvertently damage your rifle. Apply the detergent / disinfectant to a lint-free cloth and wipe clean the relevant areas of your rifle.
- It is also preferable to use polyester wipes. These only absorb approximately 7% of the active ingredient as compared to wipes made of cotton, which absorb approximately 50 - 70%.
- Detergents / disinfectants generally have a degreasing effect - if necessary, cleaned areas must be re-greased / oiled / preserved in accordance with the operating instructions.
- ANSCHÜTZ assumes no guarantee for damage to rifles, accessories, or other items caused by the use of detergents or disinfectants.
- The safety regulations and instructions for use of the detergents / disinfectants must be observed and followed.
- If you have any questions, please contact our sales team.

Yours ANSCHÜTZ-Team